

**Side-Loaded TERM-seal Ura-Fen Shield TWB
Installed as a Dampcourse on 2 course stepdown**

This method involves using a purpose designed adhesive and concrete pinning at 300mm centres

TERM-seal Ura-Fen Shield
TWB



Frame

30mm wide continuous application
of Adhesive

Concrete nail through
Adhesive at 300mm centres



Masonry



Side-Loaded TERM-seal
Ura-Fen Shield TWB



Slab

