

Side-Loaded TERM-seal Ura-Fen Shield TWB Installed as a Dampcourse

This method involves using a purpose designed adhesive and concrete pinning at 300mm centres

TERM-seal Ura-Fen Shield
TWB

Frame

Concrete nail through
Adhesive at 300mm centres

30mm wide continuous application
of Adhesive

Masonry

Side-Loaded TERM-seal
Ura-Fen Shield TWB

Slab

20mm
Inspection
zone

